



This Meter measures AC/DC Voltage, AC/DC Current, Resistance Capacitance, Frequency (Electrical & Electronic), Duty Cycle, Diode Test, Insulation Test, Continuity and Temperature. It can store and record data. It features a waterproof, rugged design for heavy duty use.



DT-9985

TRUE RMS INDUSTRIAL MULTIMETER AND INSULATION RESISTANCE TESTER

Safety Information

Input Protection Limits	
Function	Maximum Input
V DC or V AC	1000VDC/AC rms
mA AC/DC	500mA 1000V fast acting fuse
A AC/DC	10A 1000V fast acting fuse (20A for 30 seconds max every 15 minutes)
Frequency, Resistance, Capacitance, Duty Cycle, Diode Test, Continuity	1000VDC/AC rms
Temperature	1000VDC/AC rms
Surge Protection: 8kV peak per IEC 61010	



AUTORANGING/MANUAL RANGE SELECTION

This automatically selects the best range for the measurements being made and is generally the best mode for most measurements.

MAX/MIN

- will display and hold the maximum reading and will update only when a new "max" occurs.
- will display and hold the minimum reading and will update only when a new "min" occurs.

RELATIVE MODE

The relative measurement feature allows to make measurements relative to a stored reference value.

HOLD

The hold function freezes the reading on the display

PEAK HOLD

The Peak Hold function captures the peak AC or DC voltage or current. The meter can capture negative or positive peaks as fast as 1 millisecond in duration.

Data record (STORE/RECALL)

- STORE function**
Allows the instrument to STORE 2000 data with selected time interval between 1 to 255S.
- RECALL function**
Recalls the stored data with respect to each memory address.

Parameter setting up (SET)

This allows the user to set the upper limit buzzer alarm, lower limit alarm, auto power off time, set backlight time.

Technical Specifications

Function	Range	Resolution	Accuracy
DC Voltage	400mV	0.01mV	±(0.06% reading + 4digits)
	4V	0.0001V	
	40V	0.001V	
	400V	0.01V	
	1000V	0.1V	±(0.1% reading + 5digits)
AC Voltage			50 to 1000Hz
	400mV	0.1mV	±(1.0% reading + 7digits)
	4V	0.001V	
	40V	0.01V	
	400V	0.1V	±(1.0% reading + 5 digits)
	1000V	1V	
AC+ DCVoltage	400mV	0.1mV	±(1.0% reading + 7digits) (50/60HZ)
	4V	0.001V	
	40V	0.01V	
	400V	0.1V	
	1000V	1V	
All AC voltage ranges are specified from 5% of range to 100% of range			
DC Current	400µA	0.01µA	±(1.0% reading + 3 digits)
	4000µA	0.1µA	
	40mA	0.001mA	
	400mA	0.01mA	
	10A	0.001A	
	(20A: 30 sec max with reduced accuracy)		
AC Current (AC+DC)			50 to 1000Hz
	400µA	0.1µA	±(1.5% reading + 7digits)
	4000µA	1µA	
	40mA	0.01mA	
	400mA	0.1mA	
	10A	0.01A	
(20A: 30 sec max with reduced accuracy)			
AC+ DC Current	400µA	0.1µA	±(1.5% reading + 7digits)
	4000µA	1µA	
	40mA	0.01mA	
	400mA	0.1mA	
	10A	0.01A	
	(20A: 30 sec max with reduced accuracy)		
All AC current ranges are specified from 5% of range to 100% of range			

NOTE: Accuracy is stated at 65°F to 83°F (18°C to 28°C) and less than 75% RH.

AC switch according to the calibration of sine wave. It generally increase ±(2% reading + 2% full scale) if non sine wave in the wave crest less than 3.0.

Contact :

CEM INSTRUMENTS (INDIA) PVT. LTD.

32A, Ganesh Chandra Avenue, 4th Floor, Kolkata-700013

Tel: 033-22151376, 22159759

Email: info@cem-instruments.in / info@cem-india.com

Web: www.cem-instruments.in / www.cem-india.com

CEM INSTRUMENTS HEADQUATER & FACTORY

19th Building, 5th Region, Baiwangxin Industry Park,

Songbai Road, Baimang, Xili, Nanshan, Shenzhen,

China, 518108

Tel: +86-755-27353188, Fax: +86-755-27653699



Function	Range	Resolution	Accuracy	
Resistance	400Ω	0.01Ω	±(0.3% reading + 9 digits)	
	4kΩ	0.0001kΩ	±(0.3% reading + 4 digits)	
	40kΩ	0.001kΩ		
	400kΩ	0.01kΩ		
	4MΩ	0.001MΩ		
		40MΩ	0.01MΩ	±(2.0% reading + 10 digits)
Capacitance	40nF	0.001nF	±(3.5% reading + 40 digits)	
	400nF	0.01nF	±(3.5% reading + 10 digits)	
	4μF	0.0001μF		
	40μF	0.001μF		
		400μF	0.01μF	±(5% reading + 10 digits)
		4000μF	0.1μF	
		40mF	0.001mF	
Frequency (electronic)	40Hz	0.001Hz	±(0.1% reading + 1 digits)	
	400Hz	0.01Hz		
	4kHz	0.0001kHz		
	40kHz	0.001kHz		
	400kHz	0.01kHz		
	4MHz	0.0001MHz		
	40MHz	0.001MHz		
		100MHz	0.01MHz	Not specified
Frequency (electrical)	Sensitivity: 0.8V rms min. @ 20% to 80% duty cycle and <100kHz; 5Vrms min @ 20% to 80% duty cycle and > 100kHz.			
	40.00Hz-10KHz	0.01Hz - 0.001KHz	±(0.5% reading)	
	Sensitivity: 1Vrms			
Duty Cycle	0.1 to 99.90%	0.01%	±(1.2% reading + 2 digits)	
	Pulse width: 100μs - 100ms, Frequency: 5Hz to 150kHz			
Temp (type-K)	-50 to 1000°C	0.1°C	±(1.0% reading + 2.5°C)	
	-58 to 1832°F	0.1°F	±(1.0% reading +4.5°F) (probe accuracy not included)	
4-20mA%	-25 to 125%	0.01%	±50 digits	
	0mA=-25%, 4mA=0%, 20mA=100%, 24mA=125%			

Meg OHMS

Terminal Voltage	Range	Resolution	Accuracy	Test Current	Short circuit current
125V (0%~+10%)	0.125~4.000 MΩ	0.001MΩ	±(2%+10)	1mA @load125kΩ	≤1mA
	4.001~40.00 MΩ	0.01MΩ	±(2%+10)		
	40.01~400.0 MΩ	0.1MΩ	±(4%+5)		
	400.1~4000 MΩ	1MΩ	±(5%+5)		
250V (0%~+10%)	0.250~4.000 MΩ	0.001MΩ	±(2%+10)	1mA @load250kΩ	≤1mA
	4.001~40.00 MΩ	0.01MΩ	±(2%+10)		
	40.01~400.0 MΩ	0.1MΩ	±(3%+5)		
	400.1~4000 MΩ	1MΩ	±(4%+5)		
500V (0%~+10%)	0.500~4.000 MΩ	0.001MΩ	±(2%+10)	1mA @load500kΩ	≤1mA
	4.001~40.00 MΩ	0.01MΩ	±(2%+10)		
	40.01~400.0 MΩ	0.1MΩ	±(2%+5)		
	400.1~4000 MΩ	1MΩ	±(4%+5)		
1000V (0%~+10%)	1.000~4.000 MΩ	0.001MΩ	±(3%+10)	1mA @load1MΩ	≤1mA
	4.001~40.00 MΩ	0.01MΩ	±(2%+10)		
	40.01~400.0 MΩ	0.1MΩ	±(2%+5)		
	400.1~4000 MΩ	1MΩ	±(4%+5)		

Note: Accuracy specifications consist of two elements:

- (% reading) – This is the accuracy of the measurement circuit.
- (+ digits) – This is the accuracy of the analog to digital converter.

Contact :

CEM INSTRUMENTS (INDIA) PVT. LTD.

32A, Ganesh Chandra Avenue, 4th Floor, Kolkata-700013

Tel: 033-22151376, 22159759

Email: info@cem-instruments.in / info@cem-india.com

Web: www.cem-instruments.in / www.cem-india.com

CEM INSTRUMENTS HEADQUATER & FACTORY

19th Building, 5th Region, Baiwangxin Industry Park,

Songbai Road, Baimang, Xili, Nanshan, Shenzhen,

China, 518108


Tel: +86-755-27353188, Fax: +86-755-27653699



DT-9985

True RMS Industrial Multimeter and Insulation Resistance Tester

General Specifications

Store capacitance	2000
Enclosure	Double molded, waterproof
Shock (Drop) Test	6.5 feet (2 meters)
Diode Test	Test current of 0.9mA maximum, open circuit voltage 2.8V DC typical
Continuity Check	Audible signal will sound if the resistance is less than 35Ω (approx.), test current <0.35mA
PEAK	Captures peaks >1ms
Temperature Sensor	Requires type K thermocouple
Input Impedance	>10MΩ VDC & >9MΩ VAC
AC Response	True rms
AC True RMS	The term stands for "Root-Mean-Square," which represents the method of calculation of the voltage or current value. Average responding multimeters are calibrated to read correctly only on sine waves and they will read inaccurately on non-sine wave or distorted signals. True rms meters read accurately on either type of signal.
ACV Bandwidth	50Hz to 1000Hz
Crest Factor	≤3 at full scale up to 500V, decreasing linearly to ≤1.5 at 1000V
Display	40,000 count backlit liquid crystal with bargraph
Overrange indication	"OL" is displayed
Auto Power Off	15 minutes (approximately) with disable feature
Polarity	Automatic (no indication for positive); Minus (-) sign for negative
Measurement Rate	2 times per second, nominal
Low Battery Indication	"  " is displayed if battery voltage drops below operating voltage
Battery	One 9 volt (NEDA 1604) battery
Fuses	mA, μA ranges: 0.5A/1000V ceramic fast blow; A range: 10A/1000V ceramic fast blow
Operating Temperature	41°F to 104°F (5°C to 40°C)
Storage Temperature	-4°F to 140°F (-20°C to 60°C)
Operating Humidity	Max 80% up to 87°F (31°C) decreasing linearly to 50% at 104°F (40°C)
Storage Humidity	<80%
Operating Altitude	7000ft. (2000 meters) maximum.
Safety	This meter is intended for origin of installation use and protected, against the users, by double insulation per EN61010-1 and IEC61010-1 2nd Edition (2001) to Category IV 600V and Category III 1000V; Pollution Degree 2. The meter also meets UL 61010-1, 2nd Edition (2004), CAN/CSA C22.2 No. 61010-1 2nd Edition (2004), and UL 61010B-2-031, 1st Edition (2003)

Accessories

Test Leads, 6pcs Battery, Type K Temperature Probe, USB Cable and Software (9985RF), Gift Box with Carrying Case.



NO	TEMP	DATA	UNIT	TIME
0560	TEMP	0561.8	°C	10/10/18 10:10
0561	TEMP	0561.7	°C	10/10/18 10:10
0562	TEMP	0561.7	°C	10/10/18 10:10
0563	TEMP	0561.7	°C	10/10/18 10:10
0564	TEMP	0561.8	°C	10/10/18 10:10
0565	TEMP	0561.8	°C	10/10/18 10:10
0566	TEMP	0561.4	°C	10/10/18 10:10
0567	TEMP	0561.8	°C	10/10/18 10:10
0568	TEMP	0561.7	°C	10/10/18 10:10
0569	TEMP	0561.7	°C	10/10/18 10:10
0570	TEMP	0561.7	°C	10/10/18 10:10
0571	TEMP	0561.7	°C	10/10/18 10:10
0572	TEMP	0561.7	°C	10/10/18 10:10
0573	TEMP	0561.7	°C	10/10/18 10:10
0574	TEMP	0561.7	°C	10/10/18 10:10
0575	TEMP	0561.7	°C	10/10/18 10:10
0576	TEMP	0561.7	°C	10/10/18 10:10
0577	TEMP	0561.7	°C	10/10/18 10:10
0578	TEMP	0561.7	°C	10/10/18 10:10
0579	TEMP	0561.7	°C	10/10/18 10:10
0580	TEMP	0545.8	°C	10/10/18 10:10
0581	TEMP	0540.3	°C	10/10/18 10:10
0582	TEMP	1188.0	°C	10/10/18 10:46
0583	TEMP	1188.0	°C	10/10/18 10:46
0584	TEMP	OL	°C	10/10/18 10:46
0585	TEMP	OL	°C	10/10/18 10:46

Contact :

CEM INSTRUMENTS (INDIA) PVT. LTD.

32A, Ganesh Chandra Avenue, 4th Floor, Kolkata-700013

Tel: 033-22151376, 22159759

Email: info@cem-instruments.in / info@cem-india.com

Web: www.cem-instruments.in / www.cem-india.com

CEM INSTRUMENTS HEADQUATER & FACTORY

19th Building, 5th Region, Baiwangxin Industry Park,

Songbai Road, Baimang, Xili, Nanshan, Shenzhen,

China, 518108

Tel: +86-755-27353188, Fax: +86-755-27653699

